

**ENIGMA**<sup>®</sup>  
POCKET DOORS

# **Motus**<sup>®</sup> Kit Shadow-Gap

## Installation Guide

SEL-PRT-00779 | Rev. 5



**EI30 Fire Rated**  
**Power-assisted**



# Thank you for choosing Enigma

To ensure the installation process is simple and efficient, we recommended you read this guide in full first.

Specific tools are also required to complete the installation:



Pencil



Tape Measure



Knife



Laser Level




Cordless Drill Driver

## Sync Unit Wiring Tools For Double Doors




Powered  
Chop Saw




Hex Keys  
(Metric)



Flathead Screwdrivers  
(Medium & Small)



Cable Stripper  
& Cutters



Long-nose  
Pliers

## Fire certification guidance

IMPORTANT

**If fitting a fire-rated kit with a fire-rated lock or fire-rated flush door handle please refer to the field of application for intumescent detail, or contact Selo:**

We are the only doorset manufacturer to offer Halo Assist™ providing you with dedicated project support at every stage.

**call** 020 3880 0339

halo  
assist

# Getting started

Before you start installation ensure you have read and understood the instructions.

## DELIVERY

The Motus Enigma pocket Door system will be delivered in at least three boxes:

1. Pocket Frame
2. Trim Surround
3. Track

If a Door leaf has been ordered this will come separately.



## POWER REQUIREMENTS

The Motus Enigma pocket Door system requires a low-voltage electrical connection. Wiring for the system can vary based on the type of connection:

### Hardwired (Optional)

1. **13amp Fused Spur** Isolation Switch
2. **1.5mm Twin & Earth Cable** feed to the top of the Pocket enclosure

### 'Kettle-lead' Wiring (Standard)

1. **13amp** Single Socket



### IMPORTANT SAFETY INFORMATION

The unit should be installed and commissioned by a trained and qualified personnel.

The unit may only be opened and repaired by the manufacturer.

This unit may only be operated from a protective low-voltage with safe electrical isolation.

Always consider the safety functions of your application as a whole, never just in relation to one individual component of the system.


The installed is responsible for carrying out a risk assessment and installing correctly.

Avoid touching any electronic components.


# Motus® Frame kit EI30 S

Familiarise yourself with components included. All fixings will come pre-packaged to suit your specific project requirements.

## MOTUS FRAME FIXINGS



**Type-01 - B.x13.5mm**  
Wafer Head  
Self Drilling  
SEL-PRT-00685




**Type-02 - 4.5x40mm**  
Countersunk Pozi Single Slash  
Wood Screws  
SEL-PRT-00686



**Type-03 - 4x50mm**  
Countersunk Pozi  
Wood Screws  
SEL-PRT-00687



**Type-06 - 4.5x60mm**  
Countersunk Pozi Single Slash  
Wood Screws  
SEL-PRT-00690



**Type-04 - 4x30mm**  
Cross Round Head Pozi  
Wood Screws  
SEL-PRT-00688



**Type-05 - 3.5x25mm**  
Bugle Head Phillips  
Self Drilling  
SEL-PRT-00689



**Type-09 - 5x50mm**  
Countersunk Pozi Single Slash  
Wood Screws  
SEL-PRT-00693



**Type-15 - 6.0x80mm**  
Countersunk Pozi 3  
Wood Screws  
SEL-PRT-00770

## MOTUS FRAME COMPONENTS




**Base Channel**



**Head Channel**



**Leading Edge Jamb**




**Intermediate Jamb**



**Timber Insert**



**Door Guide Pin & Channel**



**Motus Sliding Track**



**Brush Strip**

# Wall construction preparation

The Motus Enigma system can be fitted to steel or timber studwork partitions. You must ensure the Head stud is strong enough to take the Door weight.

## IMPORTANT INSTALLATION NOTES

### 1. Studwork size

The studwork size required is **94mm**.  
If using steel studs a 94mm Head and base Track and 92mm uprights should be used.

### 2. Steel studs

If using steel studs, timber inserts are required within the studs to provide additional strength and purchase for 60mm Track Screws.

### 3. Doors above 2300mm

If the Door height you are installing is above 2300mm then using 2 layers of plasterboard is recommended.

To order kits to suite two layers of plasterboard add 'Double Board' to the product code.

### 4. Self-supporting Head

For situations in high rise buildings where you cannot fix to the ceiling or soffit then use the Enigma Self-supporting Head installation detail.

Follow standard Enigma instructions to calculate your studwork structural opening and add the following dimensions: **Width +94mm** and **Height +220mm**. Refer to the specific Self-supporting Head installation instructions for further details.

### Bespoke requirements?

Enigma can be customised to suit bespoke projects. In principle, the installation process remains the same, however certain installation dimensions may differ. Please contact the Selo team to discuss your bespoke requirements.

# Dimensions

## Motus EI30 Shadow-Gap



### SELF-SUPPORTING HEAD

Follow the standard Enigma instructions to calculate your studwork structural opening and add the following dimensions: **Width +94mm** and **Height +220mm**

### IMPORTANT

If installing Self-supporting Head please refer to the specific installation instructions for further details.

MOTUS TRACK SIZE

ITEM		1750mm	2000mm	2250mm
Door sizes (mm) Height = S/O -95mm	Width	875	1000	1125
	Min. Height	1500	1500	1500
	Max. Height	2815	2815	2815
Clear openings (mm)	Min. Single	600	781	906
	Max. Single	780	905	1030
	Min. Double	1000	1643	1893
	Max. Double	1642	1892	2142
Structural openings (mm)	Width Single	1870	2120	2370
	Width Double	3700	4200	4700
	Height	Door +95mm	Door +95mm	Door +95mm

### Base Channel Calculations

Please refer to Step 4 of the Frame Installation instructions shown on page 12.





### STRENGTHEN HEAD

When constructing your stud partition, please ensure the Head is strong enough to take the weight of the sliding Door that will hang from it.


#### IMPORTANT

If using a Self-supporting Head please refer to those specific installation instructions.



### CHECK SIZE WITH SCHEDULE

When forming the structural opening, please ensure you are working to the correct opening size provided on the Door schedule.




### LEVEL-UP

Ensure the opening is square and plumb.

#### IMPORTANT

We strongly recommend using a laser level for setting out.






# Frame installation

## IMPORTANT

If installing Self-supporting Head please refer to the specific installation instructions for further details.



## PREPARE THE STRIKE JAMB

### IMPORTANT

If installing double Doors skip this step.

Cut some C16 timber stud (**70mm x 45mm**) to the height of the structural opening.

Cut noggins at **26mm thick**. Space at a maximum of 500mm centres and fix to the Strike as per the drawing.




## PREPARE HEAD CHANNEL & SLIDING TRACK

### Single Doors

Cut the Head Channel to S/O width.

### Double Doors

Cut the **Head Channels** equally to take up the whole S/O. It is important to ensure that where the two Channels meet is in the centre of the opening.



## HEAD CHANNEL PREPARATION

### Single Doors

**A.** Mark **50mm** from the rear end of the **Head Channel** and **70mm** from the Strike/front end.

**B.** The Kettle Lead port is at the front of the Track and will be installed at the Strike end of the pocket. Place the **Track** on the **Head Channel** and line-up the Kettle Lead entry point with the **70mm** mark. Align the centre lines of the **Track** and the **Head Channel** together, pilot drill the screw holes.

### Double Doors

Mark **50mm** from each end. The **Tracks** will be installed with the Kettle Lead ports in the middle to aid wiring. Place the two **Head Channels** together with the Tracks inside lining up the centre lines. Ensure there is **100mm** gap between the Tracks for the wire box and then pilot drill the screw holes.

## FIT THE HEAD CHANNEL

Using a laser level, fit the Head Channel to the top stud with **Head Channel Screws** using **Type-02** Screws provided.

### IMPORTANT

It is important to ensure the Head Channel is level with no bends or bows. If the top stud is not straight then pack the Head Channel out with packers to maintain level.

### Single Doors

The 70mm gap and the Kettle Lead port should be at the Strike end of the pocket.

### Double Doors

For double ensure the Kettle Lead ports are facing each other in the centre of the opening and with 100mm gap between the Tracks.


## Base Channel length

### Single Doors EI30 S

Structural Opening -Clear Opening -170mm

### Double Doors EI30 S

Structural Opening -Clear Opening -84mm ÷ 2



## System calculations

### Structural opening examples\*

#### 1750mm wide

Single S/O	1820mm (Track +70mm)
Double S/O	3600mm (Track x2 +100mm)
Max. movement range	875mm

#### 2000mm wide

Single S/O	2070mm (Track +70mm)
Double S/O	4100mm (Track x2 +100mm)
Max. movement range	1000mm

#### 2250mm wide

Single S/O	2070mm (Track +70mm)
Double S/O	4100mm (Track x2 +100mm)
Max. movement range	1125mm

\*S/O height Door leaf +95mm

### Permitted Door leaf sizes

Min. height	1500mm
Max. height	2815mm
Min. width	875mm
Max. width	1125mm

Travel for unit = The amount which goes into the Strike Jamb.

## CALCULATE BASE CHANNEL & FIX

### Single/Double Doors

To accurately determine the length of the **Base Channel**, refer to the calculations on the left. Cut the **Base Channel** to this dimension. *Image A.*

### Base Channel fitting


Place the **Base Channel** on the floor against the rear stud.

If provided with a 'cut-to-size' system position the notched end tight against the rear stud.


At this stage it is vital that to ensure that the centre line of the **Base Channel** is secured directly underneath the centre line of the Track above. Any deviation will result in misaligned Doors and Trims. Secure to the ground with fixings suitable for substrate.

### Cover-plate (Non- Sync)

If the Sync unit is not used, screw the Cover-plate provided between the Tracks to Cover the cable.







A. Track Tounge



B. Track

## FIT TOP TRACK

**A.** Using **x4 Type-09 Screws** fix the **Track Tongue** in place ensuring it is central inside the Head Channel and up against the **rear Stud**, as shown.

**B.** Slide the **rear of the Track** into the **Track Tongue**, then, using the **Type-15 Screws**; fix the remaining x2 screw holes located at the **Front** and **Middle** of the Track (**NOT the Rear**).

Once fixed in place, the **front of the Track** should be lined-up with the **70mm** mark for a **Single Door**, or **50mm** mark for **Double Doors**. (Detailed in **Step 2**).


### IMPORTANT

Do not fix the rear of the Track (where the tongue is holding the Track in place) This is to ensure that the Track can be removed if required for servicing.



## CUT LEADING EDGE & INTERMEDIATE JAMB

Cut the **Leading Edge Jamb** and **Intermediate Jamb** 15mm less than the structural opening height.



### CUT & FIT INTERMEDIATE TIMBER INSERT

Cut the Intermediate **Timber insert** 100mm shorter than the Aluminium Jamb and slide the insert into the **Intermediate Jamb** so it sits 50mm from each end.

#### IMPORTANT

When using Door leafs wider than 926mm the kit will be supplied with extra Intermediate Jambbs to be fitted equally space within the pocket width.

### CONNECTING THE TRACK

#### Single Doors

Push the Kettle Lead in the Strike end of the Track. Run the excess cable behind the Strike Trim packer to the Plug. **DO NOT power on at this point.**

#### Double Doors

Remove the Kettle Lead ports on both Tracks. As standard; Motus Double Doors utilise a **Sync unit** to open both Doors at the same time, additional wiring is required - See **p18**.

For **Hardwired Power Supply** please see **p32**.





## FIT POCKET SIDES & FIX THE JAMB

**A.** Slide the **Intermediate Jamb** into the **Head Channel** and **Base Channel** with the **Timber inserts** facing out so it sits centrally in the pocket. Fix using **Type-01** Screws.

**B.** Slide the **Leading Edge Jamb** into **Base Channel** with notched end at the top, so the flange sits hard against the end of the **Base Channel**.

Plumb the Jamb and fix into place using one **Type-01** screw top and bottom as shown in the image. Must be posited furthest from the opening.



## FIT BRUSH STRIP

Cut the **Brush Strip** to length and fit to the **Leading Edge Aluminium profile**.

### IMPORTANT

If using simultaneous opening ensure that the **Door leafs** and **Head Trims** have been fitted. Refer to the **simultaneous opening instructions** for more.





### FIT THE DOOR STOPS

Slide the **Door Stop** into the Track, fix into place by tightening the grub Screws. This can be finally adjusted once the Trims are installed. To set the rear stop, slide the Door back into the pocket until the Door will be flush with the Leading Edge Trims, then tighten the stop up against the carriages.

#### IMPORTANT

It is important to set the rear stop at this point as once plasterboard is installed there is no access to rear stop.

### SYNC FOR DOUBLE DOORS ONLY



### DRILL HEAD CHANNEL

#### IMPORTANT

The next steps A-E refer to the installation of a Sync unit and is used with Double Doors ONLY. For Single Door installation please skip the following steps.

Work out in relation to your current internal wall cabling as to the route to the centre of the Tracks, then drill a hole **no smaller than 8mm** in the **Head Channel** as shown.

### SYNC FOR DOUBLE DOORS ONLY



### REMOVE KETTLE-LEAD PORTS


Remove the fascias on both Tracks to expose the Kettle Lead port and Connection Terminals.

**Remove x2 Screws** before removing port. Ports need to be removed from **both Tracks**.

#### IMPORTANT

Do not bend-down switchboard when removing the ports.

### SYNC FOR DOUBLE DOORS ONLY



### PREPARE CABLE

Cut the **Kettle-lead Plug** off the Power Cable supplied and thread through the **Head Channel** hole drilled previously.

Strip the cable approximately **30mm** from the ends.

### SYNC FOR DOUBLE DOORS ONLY




### CONNECT TRACKS

Wire the block to the Tracks as shown.

Connect the two Tracks together with the **Sync-cable** provided in the plugs shown.

### SYNC FOR DOUBLE DOORS ONLY



### WIRE POWER CABLE

Wire the Power Cable to the Connector Block as shown then 'power-up' the Track.


Test the Doors to ensure correct movement/function. Attached the **Cover Plate** to Cover the gap and screw into place.




# Door leaf installation

The Door leafs needs to be fitted before the intumescent seals are applied.

## FIT HEAD BRACKETS



**Single Door** Position the Brackets equally to the edges of the Door, spaced to **150mm** centres.



**Double Doors** Fit Brackets **100mm from the back** edge and **200mm from the front** so the two Doors meet in the centre over the 100mm Sync unit. (Instead of hanging equally as per the singles.)

## FIT THE GUIDE CHANNEL

Apply a thin bead of adhesive into the groove in the bottom of the Door and then tap the Plastic Channel into position.





## ASSEMBLE GEAR

Adjust the Bolts to achieve a gap approximately **15mm** between the underside of the Track and the top of the Bolt.



## HANG THE DOOR

**A.** The Bracket fits onto the Bolt as shown.

**B.** Feed the rest of the Door at least halfway into the pocket and hang the front Bracket onto the Trolley Bolt.

**C.** With spanners provided, wind the Bolts up or down to plumb the Leading Edge of the Door and to achieve the required gap under the Door (Door undercut).

Tighten the Locking Nuts to secure the Door to the Brackets. They may need to be slacked-off later, to true the Door to the Trims once they are fitted.







## CALIBRATE TRACKS

Prior to configuration ensure Doorstops are correctly fitted to avoid any potential damage.

Power-up the Motus. **Press-and-hold** the 'reset' button (both Tracks if installing a Double Door) for **3 seconds** - The LED light will flash, let go and stand clear of the Door(s) while it self calibrates. Usually the Door will open/close 2-3 times during the process. Adjust the Door levels if needed so it closes straight against the Strike Jamb.

### IMPORTANT

The Tracks must have the same Speed/Delay times to Sync correctly. These can be adjusted with the plastic screwdriver (enclosed). Do not over turn the adjustment Screws; only turn between Min and Max indicators.

Use the provided plastic screwdriver **ONLY**.



A.



B.

## FIT REMAINING POCKET SIDE

**A.** Slide the remaining **Leading Edge Jamb** into **Base Channel** with notched end at the top, so the flange sits hard against the end of the **Base Channel**.

Plumb the Jamb and fix into place using one **Type-01** Screw top and bottom as shown in the image. Must be posited furthest from the opening.

**B.** In order to support the pocket sides before plasterboarding, insert the **Pocket Packer** into the pocket as shown.

### IMPORTANT

The Pocket Packers must be used to stop the side walls bowing when fixing plasterboard to the pocket.




## PLASTERBOARD THE WALL

Plasterboard over the pocket along with the rest of the wall using the **Type-05** self drilling Screws provided. It is vital to ensure the Leading Edge Jamb remains completely vertical and plumb once boarded.

# Motus® Trim kit EI30 S


All fixings will come pre-packaged to suit your specific project requirements.

## SUPPLIED TOOLS




Spanner

## SHADOW GAP TRIM FIXINGS




**Type-05 - 3.5×25mm**  
Bugle Head Phillips  
Self Drilling  
SEL-PRT-00689

## SHADOW GAP TRIM FIXINGS (cont.)



**Type-07 - 3.5×32mm**  
Bugle Head Phillips  
Self Drilling  
SEL-PRT-00691



**Type-08 - 3.5×42mm**  
Bugle Head Phillips  
Self Drilling  
SEL-PRT-00692




**Type-09 - 5×50mm**  
Countersunk Pozi Single Slash  
Wood Screws  
SEL-PRT-00693



**Type 13 - 1.4×25mm**  
Panel Pins  
SEL-PRT-00531




## SHADOW GAP TRIM COMPONENTS




**Leading Edge Trim**

Single Door x2 / Double Door x4




**Strike Trim Pt1**

Single Door x1 / Double Door n/a




**Strike Trim Pt2**

Single Door x2 / Double Door n/a




**Head Trim**

Single Door x1 / Double Door x2




**Shadow Gap Cover Trim**

Single Door x5 / Double Door x6




**Shadow Gap Plaster Bead**



**Intumescent Seals**

15×4mm





**Intumescent Seals**

20×4mm



**Strike Jamb Seals**





## INSTALL LEADING EDGE TRIMS

Cut the **Leading Edge Trims** and the **Intumescent Strips** the height of the opening.

**A.** Remove the self adhesive backing from the Intumescent Strips and apply to the routed grooves of the **Leading Edge Trims**.

**B.** Slot the Trims over the flange on the Leading Edge aluminium Jamb, with the Intumescent Strips facing in towards the Door.

**C.** Secure into position with the **Type-05** Screws at **300mm** intervals. Please note that the timber will need to be pilot-holed first.



## INSTALL STRIKE TRIMS

**A.** Cut **Strike Trim Pt1** as per the drawing, measuring from the notch to the end that is not notched. Cut the **Strike Trims Pt2** and **Intumescent Strips** to the same length.

**B.** Remove the self adhesive backing from the Intumescent Strips and apply to the routed groove on the backs of the **Strike Trims Pt2**.

Fit the notched end of **Strike Trim Pt1** centrally in the head Channel and plumb down using a level. Fix into place using the **Type-09** Screws.

**C.** Fit the **Strike Trim Pt2** to either side of **Strike Trim Pt1** and fix into place using the **Type-06** Screws. Please note that the timber will need to be pilot-holed first.




## LINE THE DOOR UP

If required, the **Door can now be trued** into alignment with the Leading Edge Trims by adjusting the **Hanger Bolts** up or down as necessary.

When you're happy that everything is aligned and the **gaps between the Door and Trims are equal**, lock the Bolts firmly into position by winding down the **Locknuts**.

Make sure to include a section of the **Shadow-Gap Cover Trim** before lining the door up. This is to be used for positional purposes only and will be fixed in-place later.



## INSTALL HEAD TRIM

Cut the **Head Trim** and the **Intumescent Strips** to the distance between the two timber Side Jambs.

**A.** Remove the self adhesive backing from the Intumescent Strips and apply to the routed groove on the backs of the **Head Trim**.

**B.** Slot the Head Trim into place, secure into position with the **Type-05 Screws** at **300mm** intervals. Please note that the timber will need to be pilot-holed first.





### SET CLOSER STOP

Adjust the metal clip, so the Door leaf closes and is held in place, against the Strike Jamb. The closer stop must be inside by the maximum dimensions shown below:

**875mm operator = 200mm (max.)**

**1000mm operator = 250mm (max.)**

**1125mm operator = 300mm (max.)**



### 2ND LAYER OF PLASTERBOARD

The second layer of plasterboard needs to stop short of the timber frame edge by **40mm**.

This allows for the Shadow-Gap and Trims.



### FIT THE SHADOW-GAP TRIM

Cut the timber Shadow-Gap Trim to height and width. It will need to be mitred at 45 degrees in the corners.

Fix the Trim into place using **Type-13 Panel Pins**.



#### FIT THE SHADOW-GAP PLASTER BEAD

Cut the Shadow-Gap plaster bead to length mitring it at the corners.

Fix into place using **Type-08** Screws.



#### FIT BATWING STRIKE SEALS

Fit the Rubber Seals to the corners of the Strike Trim as shown.





## QUALITY CONTROL

Check the functioning of the pocket Door to ensure it opens and closes correctly.

When closed check the gaps are consistent and that there is no light bleed.



## FINISHING

Now the wall can be tape and jointed and wall and Trims painted.

### IMPORTANT

**We recommend tape and jointing not plastering.**





# Troubleshooting

Technical support helpline **020 3880 0339**



MALFUNCTION	POSSIBLE CAUSES	REMEDY
Door is switched on Door is not responding Green LED is off	No power supply available	Check power supply
	Power cable connection not firmly plugged in	Plug in the power cable connection firmly
	Power cable defective	Replace power cable
	Mains plug defective	Replace drive
Door not responding Green LED lights up	Program switch in position [0] (OFF)	Switch program switch to the desired position
	Program switch in position [II] (PERMANENTLY OPEN)	Switch program switch to the desired position
	Door was opened by double-clicking PERMANENTLY OPEN switched on	Close the door by double-clicking again
	Safety sensor on the door is active (obstacles in the sensor's detection area)	Remove obstacles and adjust safety sensors if necessary
	Cable to sensor defective	Check cable and replace if necessary
	No safety sensors connected	Check jumpers and replace if necessary Terminals must be jumpered
	Drive defective	Replace drive
LED flashes green	Learning cycle was not completed	Restart learning cycle
	Drive defective	Replace drive
Door stops while moving	Door moves stiffly	Check the door's area of movement and eliminate any reason for the stiffness
		Check track and floor guide for dirt or wear and clean if necessary
Door moves past the set OPEN or Closed position	Corresponding end stop has shifted	Readjust and retighten end stop Carry out a learning cycle
Red LED lit up constantly	Control defective	Turn the power switch off and then on again
		Replace drive

Red LED flashes cyclically 2 times	Control defective	Turn the power switch off and then on again
		Replace drive
Red LED flashes cyclically 3 times	Power range switch has been switched over	Turn the power switch off and then on again
Red LED flashes cyclically 4 times	Testable safety sensors defective	Check safety sensor and replace if necessary
	Sensor's cable defective	Check cable and replace if necessary
	DIP switches 1 to 3 set incorrectly	Check and reset DIP switch settings
Red LED flashes cyclically 5 times	Incremental encoder or incremental encoder cable defective	Turn the power switch off and then on again
		Replace drive
	Opening width set incorrectly	Reset opening width (end stops) Carry out a learning cycle
Red LED flashes cyclically 6 times	Door's area of movement is blocked	Clear the area of movement
	Opening width set incorrectly	Reset opening width (end stops) Carry out a learning cycle
Red LED flashes cyclically 10 times	Stator or stator cable defective	Turn the power switch off and then on again
		Replace drive
	Short circuit at the connection terminal	1. Eliminate short circuit 2. Turn the drive off and then on again using the power switch
Hum in final position	Unfavourable end position of the door leaf	Move end stop by at least 2 mm Carry out a learning cycle
Door leaf vibrates while moving	Guide mechanism is tight	If necessary, readjust the door leaf connection and floor guide Rotate nuts several times to fix door leaves

## Dip Switch Settings


Activate different inputs at the Connection Terminals via the Dip Switches to adjust operation modes.

- |  |  |
|--|--|
| <b>8</b> OFF = No locking function                               | ON = Locking function                                |
| <b>7</b> OFF = Reduced closing force                             | ON = Enhanced closing force                          |
| <b>6</b> OFF = Automatic Function activated                      | ON = Permanent Open Function activated               |
| <b>5</b> OFF = External motion detector activated                | ON = External pushbutton activated                   |
| <b>4</b> OFF = Internal motion detector activated                | ON = Internal pushbutton activated                   |
| <b>3</b> OFF = Test low active                                   | ON = Test high active                                |
| <b>2</b> OFF = Sensor test at secondary closing edge deactivated | ON = Sensor test at secondary closing edge activated |
| <b>1</b> OFF = Sensor test at main closing edge deactivated      | ON = Sensor test at main closing edge activated      |



# Hardwired Power Supply

How to hard-wire a permanent Power Supply to your Motus powered Enigma pocket Door system.




## MOVE END STOP

When the system is installed with permanent Power Supply, the internal Power Supply socket has to be removed.

Loosen the Screws at the End Stop and move the End Stop to the centre of the system.

### IMPORTANT

Do not remove or screw down the End Stop.




## REMOVE POWER SUPPLY COVER

Loosen the screw in the Cover of the Power Supply housing and remove the Cover (on the side where the connections are located).

### IMPORTANT


Keep the Cover and the screw in a safe place as you will require it later.



### REMOVE INTERNAL SOCKET

Carefully open the Cover of the Control Unit housing by levering it out with the tip of a flat-bladed screwdriver.

Relax the Screws of the Connection Terminals and remove the internal shockproof socket.




### LIVE & NEUTRAL CONNECTIONS

Cut the Leads to length, dismantle them and connect **L1** and **N** to the Connection Terminals of the Power Supply as shown.


#### IMPORTANT

Before starting with the installation, make sure that the Power Supply line is dead (de-energized).



### EARTH CONNECTION


Lay the grounding line through the housing of the operator as shown in the picture and connect it to the Grounding Terminal (PE).



### CONNECT EXTERNAL ACCESSORIES


Connect all external accessories, except Safety Sensors. The cables for Sensors, Push-buttons etc have to be laid inside a Cable Channel as indicated in the picture.

If additional Accessories are not required move to next Step.



### CLOSE AND SCREW-DOWN COVERS

Close the Cover of the Control Unit housing. Fix and screw down the Cover of the Power Supply housing.



### RETURN END STOP

Move the End Stop to the end of the Channel and screw it down thoroughly.

#### IMPORTANT

The End Stop must not overlap.

# Commissioning and inspection

These checks should be carried out on a routine basis to be determined based on risk assessment.

## RISK ASSESSMENT GUIDANCE

Low energy movement of the doorset is generally not protected with additional protective devices because the kinetic energy levels are not considered to be hazardous. However, use of low energy doorset movement should only be considered when the risk assessment has taken account of elderly, frail and disabled users and indicates that the risk to these users is low.

The result of the final verification and operational tests should be recorded in a log book. The log book shall refer to applicable instruction for use and shall have space available to record:

1. All maintenance and repairs carried out, including recommendations (Improvements, replacements etc)
2. All significant changes or upgrading carried out
3. Any work undertaken to the doorset
4. Name, date, signature of designated responsible person
5. Include copies of the 'Check Details' table below, filled out at periods defined in the risk assessment

INSPECTION RECORD		Name	Signed	Date / /
	✓ or ✗	Initials		✓ or ✗ Initials
Risk assessment carried out within the last 12 months.	<input type="checkbox"/>	<input type="text"/>	Test Door closing time (see Table F.2 Min Time for 90% Travel Distance).	<input type="checkbox"/> <input type="text"/>
Check Door and pocket condition ensuring no sharp edges* or other hazards. Check all essential components are fitted and in serviceable condition. <small>*If flush handles are fitted then the Doors stop should be set so the handle remains out of the pocket when open to mitigate risk of injury.</small>	<input type="checkbox"/>	<input type="text"/>	Test auto reverse function works when the Door contacts an obstruction.	<input type="checkbox"/> <input type="text"/>
Isolate the power to the doorset and check to ensure manual operation is achievable.	<input type="checkbox"/>	<input type="text"/>	If auto close is enabled ensure users are aware of this function.	<input type="checkbox"/> <input type="text"/>
Restore power and check Door cycles twice whilst initiating, led lamp should remain green when finished.	<input type="checkbox"/>	<input type="text"/>	If switches are present, check condition and function.	<input type="checkbox"/> <input type="text"/>
			If additional sensors have been fitted following risk assessment check condition and function.	<input type="checkbox"/> <input type="text"/>

Table F.2 - Minimum Travelling Time per Doorset vs. Mass of Door Leaf

Mass of Door Leaf (Kilogram)	80kg	70kg	60kg	50kg	40kg	30kg	20kg	10kg	90% Travel Distance Per Leaf (Meters)
Max. Travelling Speed (Meters/Sec)	0.21mps	0.22mps	0.24mps	0.26mps	0.29mps	0.34mps	0.41mps	0.58mps	
Min. Travelling Time (Seconds)	3.5s	B.s	3.0s	2.7s	2.5s	A.s	1.8s	C.s	0.7m
	3.9s	3.7s	3.4s	A.s	2.8s	2.4s	2.0s	1.4s	0.8m
	4.4s	A.s	3.8s	3.5s	A.s	2.7s	B.s	1.6s	0.9m
	4.9s	4.6s	C.s	3.9s	3.5s	3.0s	2.5s	1.8s	1.0m
	5.4s	A.s	4.7s	C.s	3.8s	C.s	2.7s	1.9s	A.m

## The Pocket Door ***Movement***<sup>™</sup>

Save Space. Improve Accessibility. Increase Value.

[www.enigmapocketdoors.com](http://www.enigmapocketdoors.com)

