

## INSTALLATION INSTRUCTIONS

# Glass leaf Clamp installation

### SYSTEM PREPARATION

Modified February 2020 | Revision 001



The following instructions demonstrate how to install the Enigma glass clamps to the glass door leaf.

For the pocket door kit and frame installation follow the instructions supplied with the kit.



**1.**

Place the clamp pads into place using the self-adhesive point holders. Make sure the correct pads are used for the thickness of glass being used.



**2.**

Cut 2 lengths of rubber gasket and fit into the top grooves of the other side of the clamp.



**3.**

Put one rubber gasket into place looped round as shown.



4.

Clean the glass leaf.



5.

Place the clamps on the glass leaf and tighten the bolts.



6.

Fit the clamps 150mm from the edge of the leaf to the centre of the clamp.

### IMPORTANT

If using a soft closer mechanism ensure the glass clamps line up with the soft closer roller cassette.

If using a simultaneous opening mechanism please install the clamps in conjunction with the simultaneous opening instructions.



7.

Carefully stand the door up and hang the door by hooking the clamps onto the roller bolts.



8.

Fit the cover plates by hooking them on the top and pressing down until they click into the place against the glass. Ensure the door leaf is installed and hung before fitting the cover plates to allow any adjustment.



9.

Select the right end cap to suit the glass thickness. Cut the section out to enable the cap to slide over the glass and clip onto the end of the clamp.

### 10. GLASS DOOR GUIDE

The glass door guide is fitted in place of the timber door guide pin.

For help and advice with your installation contact our experienced team:

020 3880 0339

Email [sales@enigmapocketdoors.com](mailto:sales@enigmapocketdoors.com)

